

Field or Factory Installable **K-MASS**[®] Intumescent Epoxy Covers for New or Installed Actuators



K-MASS FI
INSTALLATION MANUAL

ROTORK IQ MK3 SIZE 4/5
SIDE HANDWHEEL ACTUATORS

Side Handwheel

	PART NUMBERS					
Item	Description	Part Number	Qty			
	K-MASS FI Kit for IQ MK3 Size 2	FRIQ45S-2000	1			
1	Handwheel Shaft Extension	FRIQ45S-2401	1			
2	Handwheel Split Pin	FRIQ45S-2402	1			
3	Top Gearcase Cover - Declutch/ Handwheel Side	FRIQ45S-2100	1			
4	Top Gearcase Cover - Terminal Side	FRIQ45S-2101	1			
5	Motor Cover	FRIQ45S-2701	1			
6	Lower Gearcase Cover - Motor Side	FRIQ45S-2102	1			
7	Lower Gearcase Cover - Control Cover Side	FRIQ45S-2103	1			
8	Extended Knob Shaft	FRIQ45S-2403	2			
9	K-MASS Knob Spacer - Open/ Closed	FRIQ45S-2405	1			
10	K-MASS Knob Spacer - Local/ Stop/ Remote	FRIQ45S-2408	1			
11	New Knob - Open/ Closed	FRIQ45S-2406	1			
12	New Knob - Local/ Stop/ Remote	FRIQ45S-2409	1			
13	Spare "C" Clip	FRIQ45S-2407	1			
14	Control Cover	FRIQ45S-2702	1			
15	Terminal Cover	FRIQ45S-2703	1			
16	Top Cover - Open	FRIQ45S-2704	1			
17	Top Cover - Closed	FRIQ45S-2705	1			
18	Single Conduit Cover (Open)	FRIQ45S-2500	1			
19	Single Conduit Cover (Closed)	FRIQ45S-2501	1			
20	Triple Conduit Cover	KMCP45	1			
21	Declutch Lever Cover	FRIQ45S-2503	1			
	3M Fire Barrier Caulk (Tube)	FI-0001	1			
	Loctite Blue Thread Locker	FI-0002	1			
	Box Primary/ Spare Fasteners	FRIQ45S-2003	1			
	USB Drive (Installation Manual)	FRIQ45S-2004	1			
	Installation Manual	FRIQ45S-2005	1			



Side Handwheel

TOOLS and HARDWARE REQUIRED

ITEM	QTY
5 mm Hex-Key Wrench	1
6 mm Hex-Key Wrench	1
Torx T-30 Tamper Resistant Wrench (included) - to remove knob lockout tab	1
1/8" Flat Screwdriver - to remove small "C" Clip	1
1/8" Drift Punch - to remove and install knob shafts	1
3/16" Drift Punch - to remove and install roll pin in the handwheel	1

FASTENERS and PARTS INCLUDED WITH KIT

SOCKET HEAD CAP SCREWS				
SIZE	QTY			
M6-20	2			
M6-30	4			
M6-60	1			
M8-30	8			
M8-40	12			


HANDWHEEL EXTENSION PARTS		
SIZE	QTY	
Handwheel Shaft Extension	1	
Split Pin 6mm x 25mm	1	

KNOB PARTS INCLUDED WITH KIT

ITEM	QTY
Extended Knob Shaft and "C" Clips	2
Extended Knob Lock-Out Bolt (M6 x 60) and Washers 6mm Flat Washers (6mm)	2
OEM Plastic Knob	2
K-MASS Knob Spacers	2


Side Handwheel

Modular Intumescent Epoxy Fireproofing that can be installed in about 30 minutes in the factory or in the field.




Side Handwheel

K-MASS Knob Spacers and Knobs




New Lockout Tab Assembly




Rotork IQ MK3 Size 4/5

Side Handwheel Actuator




Step 1

Remove roll pin in the handwheel and remove handwheel.




Step 2

Install Handwheel Shaft Extension (included FRIQ45S-2401) using Roll Pin (FRIQ45S-2402 included).




Step 3

Fit top handwheel/ declutch lever side Gearcase Cover (FRIQ45S-2100).




Attach the terminal side of the Top Gearcase Cover (FRIQ45S-2101) next to motor with (2) - M8 x 40 socket head cap screws.




Step 5

Fit Motor Cover (FRIQ45S-2701) and loosely bolt to upper gearcase covers with (2) - M8 x 40 socket head cap screws.




Step 6

Fit the motor side Lower Gearcase Cover (FRIQ45S-2102) and loosely bolt to Motor Cover using (2) - M8 x 40 socket head cap screws.




Step 7

Fit the lower electronics side Gearcase Cover (FRIQ45S-2103) and loosely bolt to the motor side Gearcase Cover using (2) -M8 x 40 socket head cap screws.




Remove center caps from existing plastic knobs. Remove "C" clips and actuator knobs and retain for re-installation. Remove knob shafts and plastic washers.

Note: Knobs are different. Mark them as left or right and reinstall in original location.




Step 9

Remove lockout plate screw and retain short stainless bushing and lockout plate for re-installation. Install extended knob shafts and original plastic washers




Step 10

Install Electronics Cover (FRIQ45S-2702) and loosely bolt to upper and lower Gearcase Covers with(4) - M8 x 40 socket head cap screws.




Step 11

Install original plastic knobs, stacked with **K-MASS** knob spacers and new outer knobs (included) onto the Electronics Cover. Install "C" clips and center caps.




Install lockout plate with original bushing, washers and (1) - M6 x 60 screw to the K-MASS Electronics Cover. Apply blue Loctite thread locker (included) to this bolt only (important).



Step 13


Install the Terminal Cover (FRIQ45S-2703) and loosely bolt to the Gearcase Covers with (4) - M8 x 30 socket head cap screws.



Step 14


Install the Single Conduit Cover (FRIQ45S-2500 - Open) or (FRIQ45S - 2501 - Closed) with (4)

M6 x 30 socket head cap screws.




Step 15

Install the Top Cover (FRIQ45S-2704 - Open) or (FRIQ45S-2705 - Closed) with (4) - M8 x 30 socket head cap screws.




Install the handwheel on the Handwheel Shaft Extension using the split pin provided.



Step 17

Install Declutch Lever Cover (FRIQ45S-2503) using (2) - M6 x 20 socket head cap screws.



Step 18

Install the triple conduit cover (KMCP45). Use internal clamps to attach to cables. Place second half and use band clamp to secure. Use 3M Caulk to fill unused holes in cover.

IMPORTANT! FINAL STEPS

- 1. Hand tighten all socket head bolts to 15 ft/ lbs. Do not over-torque.
- 2. Completely fill all bolt holes with 3M CP-25WB Fire Barrier Caulk (included).





Rotork IQ MK3 Size 4/5
Installation Manual

Safety is our top priority. Ensure all safety measures are adhered to in accordance with the site, location and regulatory standards. Assemble all fasteners loosely at first, and hand-tighten upon completion of assembly.

Do NOT over torque any fasteners, doing so could damage the threaded insert or **K-MASS**.